




## CABINET PARTS

For Models: WED5700SW0  
(White/Grey)

29" ELECTRIC DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS


For Models: WED5700SW0  
(White/Grey)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	14	8541401	Spring, Door (2)	36		Door, Front
	8577188	Instructions, Installation	15	3394083	Clip, Front Panel (2)		3393549	White
	W10042960	Sheet, Cycle Feature	16	3392100	Foot, Dryer	37		Handle, Door
	8578183	Use & Care Guide		279810	Foot-Optional (Extended Length Package of 2) (Not Included)		8566057	White
	8576811	Wiring Diagram				38	3406129	Seal & Bearing Assembly
<b>Following May Be Purchased</b>						39	279393	Terminal Block Kit (For Terminal Block)
<b>DO-IT-YOURSELF REPAIR MANUALS</b>			17	279318	Terminal, Tinned & Brass (3) (Includes Illus. 39)	40	697776	Screw, 10-32 x 5/8
	677818	Dryer	18		Cabinet (Includes Illus. 4)	41	3397659	Block, Terminal
				8530603	White	51	8066217	Hinge, Top (2)
2	343641	Screw, 10-16 x 1/2	19	98234	Clip, Ground	53	691366	Idler & Pulley Assembly
3	693995	Screw, 8-18 x 3/8	20	690363	Lock, Front Top (2)	56	8066065	Belt, Drive
4	8541400	Bracket, Cabinet	21		Panel, Front	57	348780	Base, Motor
5	3396795	Cover, Block		695620	White	58	3400500	Bolt, 5/16-18 x 3/4
6	342043	Screw, 10-32 x 3/8	23	685203	Clip, Felt Pad (3)	59	8066184	Pulley, 60 Hz.
7	3396805	Panel, Rear	24	3389441	Catch, Door Assembly	62	8066206	Motor Assembly 60 Hz.
8	8546676	Clip, Door Spring	26	337189	Clip, Hinge (2)	63	660658	Clamp, Motor
10	3406107	Door Switch Assembly	27	694091	Screw, 8-18 x 3/8	64	3404162	Clamp, Motor (W/Shield)
11	697773	Screw, 6-20 x 7/8	28	8066056	Hinge, R.H.	67	3390731	Seal, Door
13	3357011	Screw, 10-16 x 1/2		8066057	Hinge, L.H.	68	3393008	Screw, 10-16 x 1/2
			33	696144	Strike, Door			
			35	695737	Door, Rear			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP AND CONSOLE PARTS

For Models: WED5700SW0  
(White/Grey)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP AND CONSOLE PARTS


For Models: WED5700SW0  
(White/Grey)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8274261	Panel, Rear Console	13	688983	Screw, 8-18 x 5/8	29	8533971	Screw, Mounting (8-18 x 5/16)
2	3401684	Wire, Jumper (Black)	14	8533951	Screw, Grounding	31	8299873	Harness, Wiring
3	693995	Screw, Hex Head	15	3395683	Connector (Motor)	33	3397269	Connector (Timer)
4		Cap, End (L.H.)	16		Top	34	3347243	Connector 6-Circuit
	8566035	White		8559800	White	35	94614	Terminal
5	3405156	Switch, Wrinkle Shield	17		Knob, Control (2)	39	3398095	Switch, Push-To-Start
7	694419	Buzzer, Mini	18	W10034380	White	48		Timer Knob Assembly
8		Cap, End (R.H.)	19	3394427	Clip-Harness		W10034750	White
9	8566032	White			Knob, Push-To-Start	50	3936144	Connector
	3399639	Switch, Temperature	20	3401144	Connector, (PTS Relay)	53	8566052	Bracket, Control
10		Screen, Lint	21	3979618	Timer, 60 Hz.	54		Panel, Control
	8557857	White	22	3397695	Wire, Jumper (Guard On/Off)		8578859	White
11	8536939	Clip, Spring	23	3396029	Wire, Jumper (Temperature)			
12	8312709	Clip-Console						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BULKHEAD PARTS

For Models: WED5700SW0  
(White/Grey)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BULKHEAD PARTS

For Models: WED5700SW0  
(White/Grey)

Illus. No.	Part No.	DESCRIPTION
1	348368	Lint Chute Assembly
2	487909	Screw, 8-15 x 1/2
3	3388703	Washer-Support
4	347139	Seal, Lint Chute
5	90767	Screw, 8-18 x 3/8
6	696302	Shield, Exhaust
7	3392519	Thermal Fuse
8	3387134	Thermostat, Internal-Bias
9	3977393	Thermal Cut-Off (Includes Illus. 15)
10	694089	Wheel, Blower (Includes Illus. 22)
11	8577230	Housing, Blower
12	3398161	Clip
13	343641	Screw, 10-16 x 1/2
14	8541818	Box, Heater
15	3977767	Thermostat, 221°F (105°C)
16	3977373	Bracket, Drum Light
17	8565582	Element, Heater
18	8066086	Drum Hole Plug
19	279457	Wire Kit, Terminal (For Heater Element Wiring Harness Repair)
20	489463	Screw, 8-18 x 5/8
21	3390647	Screw, 8-18 x 1/2
33	3406124	Bulb
34	3402841	Lens, Drum Light
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397590	Roller, Support
46	348197	Washer, Support
47	3359452	Nut, 3/8-16
48	3403413	Bulkhead
49	3403634	Socket Assembly
62	692526	Ring, Bearing (2)
63	97787	Screw, 11-16 x 3/4
66	3406130	Seal, Rear Drum
67	695587	Drum Assembly
68	692490	Baffle, Drum (2)
69	3976434	Bracket, Support
70	90296	Clip
71	3403636	Baffle, Drum (1)
73	339956	Seal

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# OPTIONAL PARTS (NOT INCLUDED)

For Models: WED5700SW0  
(White/Grey)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

## ACCESSORY PARTS

279948 Kit,  
Dryer Repair  
3406839 Dry Rack  
8522199 Kit, Dryer  
Vent Testing

## PAINT, TOUCH-UP (1/2oz.)

72017 White  
4392899 Biscuit

## PAINT, PRESSURIZED SPRAY (12 oz.)

350930 White  
4392901 Biscuit  
350938 Primer, Gray

## PAINT, BULK (1 qt.)

799344 White (Uncut)  
4392900 Biscuit(Uncut)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST